

## Operator's Guide



**TO ENABLE GAS**  
Turn key switch clockwise  
Then press START



**TO DISABLE GAS DURING LESSON**  
Press and hold STOP for 2 seconds  
**END OF LESSON**  
Turn key switch anti-clockwise



**TO MUTE ALARM**  
Press ALARM MUTE then identify cause of alarm



**TO CLEAR A FAULT**  
Press START / RESET once fault has been rectified



**TO CONTROL FAN SPEED**  
Push selector switch down to OVERRIDE  
Press - / + on increase & decrease fan speed



**CLASS EXTENSION TIMER**  
Press 'C' class timer will reset  
Alarm will sound 10 mins & 1 min at end of pre-set time  
Gas will disable after pre-set time

**WARNING - This is a gas safety device do not tamper!**



For further information refer to LabSense<sub>u/c</sub> / Installation & Commissioning instructions

### WHAT TO DO IN AN EMERGENCY

If there is high CO<sub>2</sub> (above 4950ppm) the gas will shut off automatically. Please ensure all exterior windows are opened to ventilate the space allowing CO<sub>2</sub> levels to reduce back to normal range.

If there is a fire, the emergency stops on room exits will immediately stop the gas, however the building fire alarm will also automatically stop the gas supply.

### WHAT TO DO IF A FAULT OCCURS

If a fault occurs that prevents you from getting gas, check which light is illuminated on the panel as this will explain the reason for the fault.

For a suspected product fault, call Trent Controls on **01782 844688**

### SERVICE AND MAINTENANCE

This system should be annually inspected in accordance with the manufacturers instructions. CO<sub>2</sub> and temperature sensors require annual testing to ensure safe operation.

To clean control panel use a dry cloth only.